If you're paying for SILL DECK DAMAGE



you're paying too much

X-REF#	SIZE	DEPTH	DESCRIPTION
Replacement Deck (RDS) Inswing Sills – Black Cap & Nosing			
LCH	32"	4-9/16"	ZAI4565BMRDS - Mill - Black Cap w/ Sill Cover
LCI	36"	4-9/16"	ZAI4565BMRDS - Mill - Black Cap w/ Sill Cover
LCK	32"	4-9/16"	ZAI4565BBRDS - Brz - Black Cap w/ Sill Cover
LCL	36"	4-9/16"	ZAI4565BBRDS - Brz - Black Cap w/ Sill Cover
LCP	32"	6-9/16"	ZAI6565BMRDS - Mill - Black Cap w/ Sill Cover
LCQ	36"	6-9/16"	ZAI6565BMRDS - Mill - Black Cap w/ Sill Cover
LCS	32"	6-9/16"	ZAI6565BBRDS - Brz - Black Cap w/ Sill Cover
LCT	36"	6-9/16"	ZAI6565BBRDS - Brz - Black Cap w/ Sill Cover
Replacement Deck (RDS) Inswing Sills – Walnut Cap & Nosing			
LCA	32"	5-5/8"	ZAC5625DMRDS - Mill w/ Sill Cover
J16	32"	5-5/8"	Mill - Inswing Sill
LCB	36"	5-5/8"	ZAC5625DMRDS - Mill w/ Sill Cover
J17	36"	5-5/8"	Mill - Inswing Sill
LCD	32"	5-5/8"	ZAC5625DBRDS - Brz w/ Sill Cover
J14	32"	5-5/8"	Bronze - Inswing Sill
LCE	36"	5-5/8"	ZAC5625DBRDS - Brz w/ Sill Cover
J15	36"	5-5/8"	Bronze - Inswing Sill
J06	32"	7-5/8"	Mill w/ Sill Cover
J07	36"	7-5/8"	Mill w/ Sill Cover
J08	60"	7-5/8"	Mill w/ Sill Cover
J09	64"	7-5/8"	Mill w/ Sill Cover
J10	72"	7-5/8"	Mill w/ Sill Cover
J01	32"	7-5/8"	Bronze w/ Sill Cover
J02	36"	7-5/8"	Bronze w/ Sill Cover
J03	60"	7-5/8"	Bronze w/ Sill Cover
J04	64"	7-5/8"	Bronze w/ Sill Cover
J05	72"	7-5/8"	Bronze w/ Sill Cover
Deck Only			
LCJ	36"	4-9/16"	Mill - RDS Alum Deck Only
LCM	36"	4-9/16"	Brz - RDS Alum Deck Only
LCF	36"	5-5/8"	Mill - RDS Alum Deck Only
LCG	36"	5-5/8"	Brz - RDS Alum Deck Only
LCR	36"	6-9/16"	Mill - RDS Alum Deck Only
LCU	36"	6-9/16"	Brz - RDS Alum Deck Only



The jobsite is a tough world for a sill. Conditions are never perfect and your sill is going to take a hit. Stop paying for it and start planning for it with the Replaceable Deck Sill (RDS).

RDS is the first and only sill system that eliminates the costly, time-consuming and labor-intensive task of addressing sill deck damage. Plus, RDS helps quickly identify non-level openings and address imperfect site conditions in a matter of minutes.

3 EASY STEPS

Bend

Remove sill cap. Using a putty knife, bend front edge of deck away from substrate.

Remove

Once deck is fully disengaged along the length of the sill, simply slide the deck out, away from the sill.

Replace

Slide new deck onto substrate. Tap into place with a mallet.

